



## Special Instructions for Noveske N4 Weapons with the Short Carrier Recoil System

### **CLEAR THE WEAPON**

Always keep the gun pointed in a safe direction and your finger off the trigger.

1. Remove the magazine.
2. Lock the bolt to the rear.
3. Inspect the chamber to ensure it is empty.
4. Let the bolt go forward and put the selector on safe.

**CAUTION** Use care during disassembly. The action spring is under tension and there is **no buffer retainer on N4 weapons with the Short Carrier Recoil System.**

### DISASSEMBLY

1. Push in the pivot pin (front pin).
2. Push in the takedown pin while holding both the upper and lower receiver together.  
*Caution, the action spring is under tension and there is no buffer retainer.*
3. Remove the upper receiver by pulling it up and forward at about 45 degrees from the lower.
4. Remove the buffer and action spring from the upper receiver.

Further disassembly is done in the same manner as a standard N4/M16.

### REASSEMBLY

Reassembly is in reverse order.

Phone:541-479-6117  
Fax:541-479-2555  
www.Noveske.com